

INSTALLATION INSTRUCTIONS | VCWC Series: Vintage RLM Wire Cage

The important safeguards and instructions in this manual are not meant to cover all possible conditions and situations that may occur.

Note: Before attempting installation please refer to your local electrical code.

Refer to product label markings for environmental location (indoor and/or outdoor use).

IMPORTANT SAFETY INSTRUCTIONS:

- **READ AND SAVE THESE INSTRUCTIONS FOR LATER USE**
- Product should be installed by an Electrician
- Before starting the installation, make sure all electricity has been turned off and electrical breaker has been locked out and tagged out. Turning the power off at the light switch is not sufficient to prevent electrical shock.
- Product must be mounted in locations and at heights and in a manner consistent with its intended use, and in compliance with National Electrical Code and local codes. Use of accessory equipment is not recommended.
- Do not mount near gas or electric heaters.
- Equipment should be mounted in locations and at heights where it will not readily be subject to tampering by unauthorized personnel.
- **WARNING: RISK OF SHOCK**
 - Turn off the power at fuse or circuit breaker box before installation or maintenance work.
 - Wear rubber soled shoes and work on a sturdy wooden or non-conductive ladder.
- Installing contrary to instructions may cause unsafe conditions.
- If the product has any visible damage do not install it.
- To avoid hazards to children, account for all parts and properly dispose of all packing materials.
- Call the Technical Support department at ConTech Lighting with any installation questions: 847.559.5500.

INSTALLATION

- Spread Wire Cage to fit over Shade Flange
- Capture Shade Flange between upper and lower ring
- Tighten screw to secure rings to Shade
- Do not over tighten screws to prevent distortion of Shade
- Ensure the Wire Cage is secure by gently pulling downward on the Wire Cage

