### INSTALLATION INSTRUCTIONS



For ConTech Lighting SQL6 Wall Mount (Up, Down, or Up/Down) Cylinder Fixtures

# Wall Mount (Up, Down, or Up/Down) INSTALLATION INSTRUCTIONS

Before attempting installation please refer to your local electrical code.

Fixture is designed to mount flush to wall surface.

- 1. Detach the wall mounting bracket from the back of fixture by removing screw (Fig. 1).
- 2. Determine proper orientation for the wall mounting bracket according to markings on bracket.
- 3. Mount the bracket per Figure 2.
- 4. Attach tether between fixture and wall mounting bracket to aide in wiring.
- 5. Follow the wiring diagram from Figure 3 for the appropriate electrical/dimming option.
- 6. Carefully feed any excess wire into junction box to avoid pinching wires.
- 7. Reattach cylinder to mounting bracket and secure in place with screw from step 1.
- 8. For fixtures rated and installed in wet location: apply an outdoor rated caulk between the wall and fixture to ensure water tight seal.

## **IMPORTANT SAFETY INSTRUCTIONS:**

- Read all the instructions before installation. Save instructions for later use.
- Turn off power at fuse or circuit breaker box before installation or before doing any maintenance work.
- Product must be grounded to avoid potential electric shock and any other potential hazards.
- Product must be mounted in locations and at heights and in a manner consistent with its intended use, and in compliance with National Electrical Code and local codes. Use of accessory equipment is not recommended.
- Installing contrary to instructions may cause unsafe conditions.
- Do not block light from the trim aperture, in whole or in part, as this may cause unsafe conditions.
- Warning: Risk of fire. Most dwellings built before 1985 have supply wire rated at 60°C. Consult a qualified electrician before installation.
- Avoid hazards to children: account for all parts and properly dispose of all packing materials.
- Call the Technical Support department at ConTech Lighting with any installation questions: 847.559.5500.

#### WARRANTY:

• Energy Star products are covered for three (3) years by a full replacement guarantee after date of installation. In addition, ConTech LED products carry a five (5) year limited warranty from date of purchase. The Up/Down Wall Mount Fixture is not Energy Star Listed.







#### 120-277V 0-10V Dimming (MVD2)



All specifications subject to change without notice. For ConTech's limited product warranty, go to www.contechlighting.com. For a printed copy of the warranty, call 1-847-559-5500.